



B1	Supply air temperature sensor	FG1	Supply air damper actuator	PF	Air filter	VP	Remote control panel
B2	Extract temperature sensor	FG2	Extract air damper actuator	QS1	Main switch	V1	Supply air fan
B3	Outdoor temperature sensor	HE	Electric heater	dP1, dP2	Differential pressure switch for filter	V2	Exhaust air fan
B4	Exhaust temperature sensor	M1	Rotor drive	RG1	Main controller		
				RT	Rotary Heat Exchanger		
							FUNCTIONAL DIAGRAM VERSO R 1000 FSA